Mr. Do!™

...THE APPLE OF YOUR EYE!

- NONSTOP ACTION
- NONSTOP PLAY
- NONSTOP EARNINGS

EXPANDS THE WORLD OF PLAY

UNIVERSAL

©1982 UNIVERSAL CO LTD All Rights Reserved

Mr. Do!™

EXPANDS THE WORLD OF PLAY
UNIVERSAL

...THE APPLE OF YOUR EYE!

NONSTOP ACTION • NONSTOP PLAY • NONSTOP EARNINGS

HOW TO PLAY

- Operate Mr. Do! to exterminate all the monsters!
- Mr. Do! continues to eat cherries while making its passage. (High score awarded when many cherries have been eaten)
- A monster arises from its nest in the center of the screen, and chases Mr. Do! along the passage. The monster, after changing shape, may make its own.
- A cake (center target) will appear out of the same nest from which all the monsters have arisen. When Mr. Do! eats it, the monsters stop for a while, and an EXTRA monster will appear. These monsters can *only* be destroyed by Mr. Do!'s powerball!
- An EXTRA monster will also appear every time 5,000 points have been scored. Wiping out all EXTRA monsters awards another Mr. Do!
- A power ball can be hit at a distant monster, or can be effectively used to drive back the monster when it gets close.
- An apple can be moved freely even outside the passage so that it can be dropped onto the monster's head. (The monster can move an apple similarly)
- A sparkling diamond appears from an apple which has been broken after dropping more than 2 stages, you are lucky! Get it and win a replay!

Throw the power ball to wipe out the monsters

Eaten Cherry

Crush the monster by dropping an apple. Crushing many monsters at one time awards a high score.

SCORING

- When wiped out by using a power ball — 500 pts
- When crushed by an apple — 1 000 pts
- When more than 2 monsters have been crushed — 2,000 pts or more

Cherry
50 pts (500 pts when 8 cherries have been eaten in a row)

1,000	1,500	2,000	2,500	8,000 + 1 replay

SPECIFICATIONS

Table Type 95-2447
564(D)×863(W)×570-680(H)m/m
AC100V 115V 230V 50/60 Hz
140W (14") 180W (20")

Upright Type 95-1653
800(D)×640(W)×1750(H)m/m
AC100V 115V 230V 50/60Hz
180W (20")

EXPORT DIVISION

Universal Sales Co., Ltd.
1-7-7 Nihonbashi Horidome-cho Chuo-ku, Tokyo 103, Japan
Phone 03-661-1447, 6004 Cable UNMANIFACT
Telex J27348 (UNICO)

Universal U.S.A. Inc.
3250 Victor Street, Santa Clara, California 95050, U.S.A.
Phone (408) 727-4591 Telex 173347 (UN USA SNTA)
Main Line of Business Development, Manufacture, sales and exports & imports of amusement machines

European Office
81 Tottenham Court Road, London W1A 1EY
Phone 01-631-1713 Telex 892989 ELCOIN

©1982 UNIVERSAL CO.-LTD. All Rights Reserved